



Commonwealth Trailer Rentals, Inc.

866-839-3495 | RentCTR.com

Ashland, VA | Cloverdale, VA | Garner, NC | Lexington, SC | Statesville, NC

Helpful Hints for Refrigerated Trailers

1. Maintain visual contact with the microprocessor once per hour to insure that there are no alarms and the set-point is maintained.
2. Maintain at least $\frac{1}{4}$ tank of fuel at all times. (should the fuel run dry you will need to prime the unit, which could result in a service call)
3. Should the unit run out of fuel, be sure to turn the unit to the off position. By doing this you will insure that the battery and starter will not fail before the unit is able to be primed.
4. Keep the doors closed at all times while the unit is running. Failure to do so could result in an out of range alarm, undesired set-point or frozen evaporator. Any of these could result in a service call.
5. Be sure to check Fluid levels (oil, coolant) daily to insure proper use of the refrigeration unit.
6. Refrigerated Trailers are designed to maintain temperature. Do not expect a warm product to be pulled down to set-point.
7. If utilizing a multi-temperature trailer, make sure all moveable bulkheads are securely in place. This will insure proper set-point for each zone.
8. Keep the return air bulkhead free of debris at all times. This will insure proper use of the unit.
9. Check for, report and repair any holes or cuts in the kemlite. This will insure proper use of the unit.
10. Report engine hours and mileage to CTR each month. This will insure that preventative maintenance is performed, thus resulting in less down time.
11. Check all lights to make sure they are functioning properly.
12. Check the air pressure for the tires; tread depth for tires and brake linings to determine if maintenance needs to be performed.
13. Return the trailer clean to avoid additional cleaning charges.
14. Return the trailer with the proper amount of fuel to avoid additional fuel charges.

CTR Representative _____

Customer Signature _____

Date _____